


# USER GUIDE



VB0109

## MODELS

### CONSTRUCTO 1.5

### CONSTRUCTO 2.0

**READ AND SAVE THESE INSTRUCTIONS**



CONGRATULATIONS! You have made an excellent choice!

We have prepared this User Guide especially for you. Please read it carefully to ensure you obtain full benefits from your Heat Recovery Ventilator unit.

## About this Guide

This guide uses the following symbols to emphasize particular information:

**⚠ WARNING**

Identifies an instruction which, if not followed, might cause serious personal injuries including possibility of death.

**CAUTION**

Denotes an instruction which, if not followed, may severely damage the unit and/or its components.

NOTE: Indicates supplementary information needed to fully complete an instruction.

## TABLE OF CONTENTS


<b>1.0</b>	<b>UNIT DESCRIPTION</b>	<b>3</b>
1.1	SPECIFICATIONS	3
<b>2.0</b>	<b>FUNCTION OF THE HEAT RECOVERY VENTILATOR</b>	<b>3</b>
2.1	HEAT RECOVERY	3
2.2	DEFROSTING	3
<b>3.0</b>	<b>CONTROLS</b>	<b>4-6</b>
3.1	INTEGRATED CONTROL	4
3.1.1	BOOT SEQUENCE	4
3.2	OPTIONAL MAIN WALL CONTROLS	4
3.2.1	LITE-TOUCH CONSTRUCTO	4
3.2.2	CONSTRUCTO	5
3.3	OPTIONAL AUXILIARY CONTROLS	6
3.3.1	DEHUMIDISTAT	6
3.3.2	20-MINUTE LIGHTED PUSH BUTTON	6
3.3.3	60-MINUTE MECHANICAL TIMER	6
<b>4.0</b>	<b>MAINTENANCE</b>	<b>7</b>
4.1	REGULAR	7
4.2	PROLONGED	7
<b>5.0</b>	<b>TROUBLESHOOTING</b>	<b>8</b>

**CAUTION**

- Some activities create dust or vapors which may damage your unit. You must, therefore, turn off and unplug your unit in the following situations:
  - major renovation work
  - housing construction
  - sanding (e.g. gypsum joints, etc.)
  - varnishing
- During heavy snow storms, turn off the unit to avoid problems caused by snow penetration, even if it is equipped with anti-gust intake hood.
- Power disturbances or very short power failures may cause the electronic control microprocessor to malfunction. If it does, disconnect the power plug from the outlet and wait approximately 30 seconds, then plug it back in to resume operation.

## 1.0 UNIT DESCRIPTION

1. Filters
2. Blowers
3. Condensation tray
4. Heat recovery core



### 1.1 SPECIFICATIONS


MODEL	CONSTRUCTO 1.5	CONSTRUCTO 2.0
WIDTH	30 1/4" (768 MM)	30 1/4" (768 MM)
HEIGHT	16 1/2" (419 MM)	16 1/2" (419 MM)
DEPTH	17 1/4" (438 MM)	17 1/4" (438 MM)
WEIGHT	66 LB. (30 KG)	68 LB. (30 KG)
ELECTRICAL SUPPLY	120 V, 60 Hz	120 V, 60 Hz
POWER CONSUMPTION	115 W	240 W

## 2.0 FUNCTION OF THE HEAT RECOVERY VENTILATOR

Your ventilation system will help eliminate poor air quality problems by drawing the stale and humid air out of the house and replacing it with fresh outside air. By eliminating accumulated pollutants and humidity, it maintains an optimum air quality and an ideal relative humidity during cold season.


The unit is also equipped with a heat recovery core which reduces ventilation costs in winter.

*Shown with a forced air heating system; can also operate on its own.*



### 2.1 HEAT RECOVERY

Units equipped with a heat recovery core can reduce ventilation costs in winter. The unit draws the heat from the stale air and humid air before it is released and uses it to heat the air coming in from outside. The recovery core is designed in such a way that the stale air is never mixed with the fresh air.




### 2.2 DEFROSTING

When the outside temperature is below -5°C (23°F), heat recovery creates frost in the core. To maintain its proper operation, the unit is programmed to defrost the recovery core. The defrosting frequency varies according to outside temperature. Defrosting lasts 7 or 10 minutes, according to outside temperature. During the defrost cycle, the unit shifts to maximum speed and the dampers close. After defrosting, the unit returns to the operating mode previously selected by the user.

## 3.0 CONTROLS

### 3.1 INTEGRATED CONTROL

All units are equipped with an integrated control, located in front of the electrical compartment. Use the push button (1) to control the unit. The LED (2) will then show which mode the unit is in.



Refer to table below to see how to operate the unit using its integrated control.

PRESS ON PUSH BUTTON	LED COLOR	RESULTS
ONCE	AMBER	UNIT IS ON LOW SPEED
TWICE	GREEN	UNIT IS ON HIGH SPEED
THREE TIMES	NO LIGHT	UNIT IS OFF

If a problem occurs during the unit operation, its integrated control LED (2) will blink. The color of the blinking light depends on the type of error detected. Refer to *Section 5 Troubleshooting* on last page for further details.

#### 3.1.1 BOOT SEQUENCE

The unit boot sequence is similar to a personal computer boot sequence. Each time the unit is plugged after being unplugged, or after a power failure, the unit will perform a 30-second booting sequence before starting to operate. During the booting sequence, the integrated control LED will light GREEN or AMBER for 5 seconds, and then will shut off for 2 seconds. After that, the LED will light RED for the rest of the booting sequence. During this RED light phase, the unit is checking and resetting the motorized damper position. Once the motorized damper position completely set, the RED light turns off and the booting sequence is done.

NOTE: No command will be taken until the unit is fully booted.

### 3.2 OPTIONAL MAIN WALL CONTROLS

For more convenience, this unit can also be controlled using an optional main wall control.

NOTES: 1. The integrated control must be turned OFF to use an optional main control.

2. If an optional auxiliary control is used, if activated, this auxiliary control will override the optional main control.


#### 3.2.1 LITE-TOUCH CONSTRUCTO

**Location:** Located in the busiest area of the house.

**Purpose:** To adjust air supply.

Activate the push-button. The color of the indicator shows the unit operating mode.

Color	Mode	Suggested Use
Green	Intermittent	Select this mode when you are away from the house for a few days. Also, when you deem the inside air is too dry in heating season, or too humid in cooling season. In this mode, the unit is OFF for 40 minutes per hour and ventilates at minimum speed the remaining 20 minutes of the hour.
Yellow	Min. Speed Ventilation	For normal daily operation.
Red	Max. Speed Ventilation	For excess pollutants and humidity (parties, odors, smoke, etc.).



## 3.0 CONTROLS (CONT'D)

### 3.2 OPTIONAL MAIN WALL CONTROLS (CONT'D)


#### 3.2.2 CONSTRUCTO

**Location:** Located in the busiest area of the house.

**Purpose:** To adjust air supply and select desired indoor humidity level.

#### **Adjusting the AIR SUPPLY CONTROL:**

- a) Select speed MIN. or MAX. using switch **A** (as shown on diagram).
  - Select speed MIN. (minimum speed) for normal daily operation (24 hours a day all year round).
  - Select MAX. (maximum speed) for excess pollutants and humidity (parties, odors, smoke, etc.)
- b) To **turn the unit off**, place selector at the OFF position. However, if optional auxiliary controls are used, they will still be active.



#### **Adjusting the HUMIDITY CONTROL:**

##### **Setting during the summer months:**

Normally, there is no condensation on your windows during this period which, therefore, eliminates the need of the humidity control. Set knob **B** to SUMMER position during this period.

##### **Setting during the fall, winter and spring months:**

- **METHOD 1** (fast and simple for new users):
  - a) Determine approximately the outside daytime temperature.
  - b) Set knob **B** to this temperature.

NOTE: Continue using this method for about a month before trying Method 2 suggested below.

- **METHOD 2** (more precise adjustment):

Use METHOD 2 (steps **a** to **f** below) if there is condensation on your windows after using METHOD 1 for at least 1 month. As ventilation needs vary from one house to another (depending on cooking habits, frequency of showers, washing, window design, etc.), an adjustment based on outside temperature may not adequately solve the condensation problem in your house.

  - a) Select speed MIN.
  - b) Turn knob **B** clockwise until you hear a click.
  - c) Turn knob **B** a notch below the click.
  - d) 12 to 24 hours later, check if there is still condensation on the windows.
  - e) If there is, repeat steps **b**, **c**, **d** above (until desired results are obtained).
  - f) Compare the two values: the one obtained with METHOD 1 and the other with METHOD 2. Use the variance for future reference. For example, if there is a 3-degree variance, you can conclude that, for your house, an adjustment of 3 degrees below the outside temperature is required for optimum condensation control.

### CAUTION

**Do not select a temperature below -20°C. This could lead to excessive dryness in the air causing discomfort for the occupants.**

**It is possible (and normal) to experience condensation on your windows when drastic changes in temperature occur (e.g. -5°C [23°F] to -20°C [-4°F]). In that case, we suggest waiting a few days to allow the situation to stabilize.**

## 3.0 CONTROLS (CONT'D)

### 3.3 OPTIONAL AUXILIARY CONTROLS

#### 3.3.1 Dehumidistat

**Location:** Located in the bathroom or in other locations where there is temporary humidity excess.

**Purpose:** To eliminate excess humidity produced by showers or other periodic activities producing humidity.

**In the fall, winter and spring:**


Adjust knob to the desired humidity level.

#### CAUTION

**Do not select a humidity level below 30%. This could lead to excessive dryness in the air causing discomfort for the occupants.**

**In summer:**

Set knob to the SUMMER position.




VC0083

#### 3.3.2 20-Minute Lighted Push Button

**Location:** Located in the bathroom or in other locations where there is temporary humidity excess or pollutants.

**Purpose:** To eliminate excess humidity produced by showers or other periodic activities producing pollutants.

Press once to activate the push-button. The unit will operate on high speed for 20 minutes and the indicator will light up. To stop activation before the end of the 20-minute cycle, push one more time. The unit will get back to its previous setting.




VC0082

#### 3.3.3 60-Minute Crank timer

**Location:** Located in the bathroom or in other locations where there is temporary humidity excess or pollutants.

**Purpose:** To eliminate excess humidity produced by showers or other periodic activities producing pollutants.

This control makes the system operate at high speed for periods varying from 10 to 60 minutes.



VC0017

---

## 4.0 MAINTENANCE

---

### WARNING

In order to prevent personal injury, turn off the unit and unplug it before performing maintenance. When cleaning the unit, it is recommended to wear safety glasses and gloves.

---

#### 4.1 REGULAR

**Air filters:** The air filters are washable. Under normal conditions, we recommend to wash them every 3 months.

- Use a vacuum cleaner to remove the heaviest portion of accumulated dust.
- Then, wash in water and mild soap.
- Let dry completely before reinstalling them in the unit.

**Heat Recovery Core:**

### CAUTION

Hot water and a strong detergent will damage the heat recovery core.

---

The heat recovery core must be handled with care. We recommend to wash it once a year, at the end of summer, in order to ensure maximum efficiency of the plastic partitions. Allow the heat recovery core to soak for 3 hours in a solution of warm water and mild soap. Rinse under a heavy stream of water. Let dry completely before reinstalling it in the unit.

NOTE: When plugging back the unit, it will return to its previous setting after a 30-second delay for boot sequence.

**Intake hood:** Regularly check the screen in the exterior intake hood and clean when necessary. Also check during very cold weather because ice may build up on the screen located in the exterior intake hood.

**Motor:** The motor is factory lubricated for life. Do not oil bushings.

---

#### 4.2 PROLONGED

Annual service should include:

- Cleaning filters, heat recovery core and the exterior intake hood.
- Cleaning the blades of the blower wheels.
- Cleaning the condensation tray with soapy water (make sure that the drain is not clogged).

NOTE: Ask your installer for an annual service contract.

## 5.0 TROUBLESHOOTING

If you think your unit is malfunctioning, check some of the following:

TYPE OF PROBLEM		TRY THIS...
1	Nothing works.	<ul style="list-style-type: none"> <li>• See if the unit is plugged in.</li> <li>• See if the breaker is receiving power from the house circuit breaker.</li> </ul>
2	Condensation on windows (air too humid).	<ul style="list-style-type: none"> <li>• Adjust the humidity control knob as per instructions (see Section 3.0).</li> <li>• Operate the unit at maximum speed (MAX.) during activities generating excess humidity (family gatherings, extra cooking, etc.)</li> <li>• Leave curtains half-open to allow air circulation.</li> <li>• Store all firewood in a closed room with a dehumidifier or in a well ventilated room or store the wood outside.</li> <li>• Do not adjust the thermostat of your heating system below 18°C (64°F).</li> </ul>
3	Air too dry.	<ul style="list-style-type: none"> <li>• Do not adjust your humidity control below -20°C (-4°F).</li> <li>• Operate the unit at low speed (MIN.) or in intermittent mode (with Lite-Touch Constructo).</li> <li>• Temporarily use a humidifier.</li> </ul>
4	Air too cold at the air supply grille.	<ul style="list-style-type: none"> <li>• Make sure the stale air exhaust hood outside the house is not blocked.</li> <li>• Operate the unit at low speed (MIN.) or in intermittent mode (with Lite-Touch Constructo).</li> <li>• Have the system's balancing checked.</li> <li>• Have the unit's defrosting system checked.</li> <li>• Install a duct heater.</li> </ul>
5	The LED of the integrated control is blinking red.	<ul style="list-style-type: none"> <li>• There is a problem with the motor. The unit is OFF. Contact your installer.</li> </ul>
6	The LED on the integrated control is blinking green.	<ul style="list-style-type: none"> <li>• There is a problem with the thermistor. The unit is still working, but is always in defrost mode. Contact your installer.</li> </ul>
7	The LED on the integrated control is blinking amber.	<ul style="list-style-type: none"> <li>• There is a problem with the motorized damper. The unit is OFF. For a 12-hour period, the unit will try to reset the damper at every 20 to 30 minutes. After 12 hours, if the problem is not solved, the unit stops trying to reset damper. Contact your installer.</li> </ul>
8	The integrated control push button does not work.	<ul style="list-style-type: none"> <li>• The 30-second boot sequence is not completed. See integrated control on page 4.</li> </ul>

If the problem continues, contact your installer at the phone number and address listed below or call the following number for authorized service center nearest you:

- **1-800-567-3855 (CANADA AND U.S.A.)**

### YOUR INSTALLER'S ADDRESS